


Shown without Hood or Fascia option Shown with Keylock option

Inside Mount Under Lintel



View from Coil Side




Shown without Hood or Fascia option Shown with Thumb Turn option



Inside Mount Under Lintel

Motorized Operation

View from Coil Side



Shown without Hood or Fascia option




Inside Mount Under Lintel

Motorized Operation - Details



View from Coil Side




Shown without Hood or Fascia option

Inside Mount Under Lintel

Hand Crank Operation

View from Coil Side






Shown without Hood or Fascia option Shown with Keylock option

Inside Mount Under Lintel

Hand Crank Operation - Details




View from Coil Side




Shown without Hood or Fascia option Shown with Thumb Turn option


End Plate size details





Inside Mount Under Lintel









Inside Mount Under Lintel

